



**15301831**  
Edition 1  
March 2009

# Combination Assembly

**1000 Series**

---

## Parts Information



**Save These Instructions**


**airpumping.co.uk**

*of 2009*

Unit 16, Upminster Trading Park, Wainley St., Upminster, Essex, RM14 3PL, ENGLAND

**IR** *Ingersoll Rand*

Combination Assembly 1000 Series C381X1-XXX Exploded Diagram



(Dwg. 15318629)

---

**Combination Assembly 1000 Series C381X1-XXX Parts List**

---

Item	Part Description	Material	Part Number
1	Filter (See Part List 15301799)	---	F351X1-XXX
2	Regulator (See Part List 15301807)	---	R371X1-XXX
3	Lubricator (See Part List 15301815)	---	L361X1-XXX
*	Piggyback (See Part List 15301823)	---	P391XX-XXX
4	I-Bracket	Acetal	104399
5	Bolt	Steel	
6	Nut		
7	T-Bracket	Acetal	
8	Combination "O" Ring	Nitrile	

\* Not Shown

---

**Parts and Maintenance**

When the life of the product has expired, it is recommended that the product be disassembled, degreased and parts be separated by material so that they can be recycled.

Product repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

---

**Related Documentation**

For additional information refer to:

Safety Information Manual 15301765.

Product Information Manual 15301773.

Maintenance Information Manual 15301781.

Manuals can be downloaded from [fluids.ingersollrand.com](http://fluids.ingersollrand.com).

